FOR BELGIAN, FRENCH AND WESTERN EUROPEAN MODEL

5 ISD Set using ISO Screws

Serial No. 40,501 and later



#### **SPECIFICATIONS**

Picture tube: 9" 90° deflection aluminized

screen; 230DB4

Channel coverage:

Antenna system:

VHF; French

F2, F4 - F12

CCIR Western

European, Belgian E2-E12

Italian B(E-4),

D(E-5),

H(E-10)

21-69

UHF; CCIR and French

Built-in telescopic antenna

Terminals for 75 ohm external

antenna

Disc turret type for VHF band

(BT-435M)

Continuous tuning type for UHF

band (BT-186)

IF circuit: 3 stages with 4 stagger tuned

elements

Video bandwidth; 3.8 MHz/-3 dB

		Video IF (AM)	Sound IF (AM)
Intercarrier system	CCIR	38.9 MHz	33.4 MHz
	French VHF French UHF	38.9 & 34.9 38.9	27.75 & 46.05 32.4
Separate- carrier system	Belgian (625 lines)	38.9	33.4
system	Belgian (819 lines)	38.9	

Transistors: 32

Diodes: 17 IC:

Power rectifier: 1 (selenium) High voltage rectifiers: 3 (selenium)

Sound system: 5.5 MHz intercarrier

Separate systems (Can be selected by push button provided in the set) Power amplifier; OTL system Power output; 300 mW Speaker;  $2\frac{3}{4}$  '' ×  $3\frac{15}{16}$  '' oval type,

40 ohms

REC OUT jack: Impedance 1k ohm, level -60 dB

(0.78 mV)

Forward AGC (VHF tuner & VIF), Automatic controls:

Reverse AGC (SIF) and Single

pulse AFC

Power requirements

& consumptions: AC 110, 130, 220 volts, 50/60 Hz

21.5W (maximum)

DC 12 volts 13.0W (maximum) 813/16" (W) x 101/2" (H) x 95/8" (D)

Dimensions:

 $(224 \times 266 \times 245 \text{ mm})$ 

Weights: 12 lb (5.6 kg)






#### TABLE OF CONTENTS

Title	Page	Title	Page
Specification for the TV9-90UM	. 1	SCHEMATIC DIAGRAM	
BLOCK DIAGRAM  EXTERNAL VIEW  MAJOR PARTS LOCATION  DISASSEMBLY	. 3	Tuner circuit Signal circuit FM SIF circuit Power supply block Deflection circuit	. 21 . 25 . 26
Rear Cabinet Removal:	. 5	MOUNTING DIAGRAM	
Glare Filter Removal Deflection Circuit Block Removal High Voltage Block Removal Signal Circuit Board Removal FM SIF Block Removal UHF Tuner Removal VHF Tuner Removal Picture Tube Removal Speaker Removal	. 6 . 7 . 7 . 9 . 9 . 10	Conductor Side Tuner circuit Signal circuit FM SIF circuit Deflection circuit Component Side Tuner circuit Signal circuit FM SIF circuit	. 19 . 25 . 29 . 18 . 23
ADJUSTMENTS PROCEDURE		Deflection circuit	
VIF Adjustments SIF Adjustments AM-SIF Adjustments Deflection Circuit Adjustments	. 13	Power supply block  SCHEMATIC DIAGRAM  Overall	
TERMINAL VIEW		EXPLODED VIEW	. 35
Semiconductor	. 16	PACKING	. 41

#### BLOCK DIAGRAM



## SONY®

# Complete Spare Parts List

## Model TV9-90UM

(Serial No. 40,501 and later)

#### "IMPORTANT"

When ordering parts, please do not fail to furnish us the following:

- 1. Part Number
- 2. Model Name
- 3. Description as mentioned in this parts list

We are now using EDPS (Electronic Data Processing System) in all the departments concerned, for procurement, inventory control, packing, warehousing, etc. Your orders are processed mainly from the PART NUMBERS referred by you. Incorrect part numbers, therefore, will result in incorrect parts shipment. To assure prompt shipment of correct parts, your cooperation will be appreciated.

#### NOTE:

Prices are subject to change without notice.

#### COMPLETE SPARE PARTS LIST FOR TV9-90UM

(Serial No. 40,501 and later)

JANUARY, 1972

Unit <u>Price</u>

	Part No.	Description
		I. MECHANICAL PARTS
78	X-40128-01	Cabinet Ass'v. front
1	X-40128+02	Cabinet Ass'y, front
450	X-40128-03	Knob Ass'y, fine tuning
	X-40128-04	Cabinet Ass'y, rear
	X-40128-05	Clamp Ass'y, power cord
	X-40032-04	Mounting Bracket Ass'y, picture tube
	X-40062-16	Knob Ass'y, VOL control
	X-40074-07	Knob Ass'y, UHF dial
	X-40097-05-2S	Handle Support Ass'v left
	X-40097-06-2S	Handle Support Ass'y, right
	X-40097-07	UHF Dial Ass'y
	X-40097-09	Handle Support Ass'y, right
		the contract of the contract o
	4-012-808	Mounting Bracket, pushbutton switch
	4-012-809	Mounting Bracket, signal circuit board
	4-012-810	Shield Case
	4-012-811	Shield Cover
	4-012-813	Holder, selenium rectifier
	0-051-221	Spacer, pushbutton switch
	3-001-706	Clamp, cord
	4-002-847-02	Clamp, antenna
	4-003-220	Grounding Spring, picture tube
	4-003-506	Drive Screw
	4-005-359	Clamp, lead
	4-005-556	Clamp, lead
	4-005-565	Cushion, picture tube
	4-006-103-04S	Support, power transformer
	4-006-233	Control Knob
	4-006-255	Terminal Pin
	4-007-208	Spacer
	4-007-411	Control Knob  Terminal Pin  Spacer  Mounting Bracket, picture tube
	4-007-455	Mounting Wire Ring, picture tube
	4-009-724	Protector, picture tube
	4-009-725	Hold, protector
	4-009-726	Carrying Handle
	4-009-729-02S	Mounting Wire Ring, picture tube Protector, picture tube Hold, protector Carrying Handle Screw, handle

Ref.				Unit
No.	Part No.	Description	1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -	Price
		III. ELECTRICAL PAR	ΓS	
	r			
	e e e e e e e e e e e e e e e e e e e	<u>General</u>		*
	0.000 155 15			
	8-980-155-15 1-463-004	VHF Tuner Ass y (BT-	435M) 186)	
	8-980-159-25	Signal Circuit Roard	(BC), complete	
	8-980-159-35		pard (EF), complete	
	8-980-159-95		Board (FM, SIF), compl	
		Len of type forest	* v' * v 1 · 3	· .
		Market Market	i i i i i i i i i i i i i i i i i i i	Strain Control
		Semiconductors	,	
			14. 人名英格兰	Tark to the
Q301	•		7	
Q302		Transistor, 2SC65		
Q303			)	
Q304		Transistor, 2SC633		
Q305		Transistor, 2SA67	/ )	
Q351	2	,		
Q352 Q353	e	Transistor, 2SC657 Transistor, 2SC629	)()	
Q354		Transistor, 2SC629	)	
Q355 Q355		Transistor, 2SC65	7	
Q356	the second secon	Transistor, 2SC629	98	
Q357		Transistor, 2SC63	3<	<u></u>
Q501		Transistor 280401	34	
Q502	with the second of the second	Transistor. 2SC403	A milesiana	
Q503		Transistor, 2SC112	27	
Q551	de e	Transistor, 2SC403	3. 4 4 <sub>4</sub> <sub>4</sub> <sub>4</sub> <sub>4</sub>	
Q552	• • • • • • • • • • • • • • • • • • •	Transistor, 28B324	4	
Q553				
Q554	· · · · · · · · · · · · · · · · · · ·		<u> </u>	
Q601			2 #1	÷ • • · · · · · · · · · · · · · · · · ·
Q602	and and		};	
Q701			7).+-4=	
Q702	•		//  //	
Q703	e		380	
Q801			) 	
Q802		Transistor, 2SD293 Transistor, 2SC800	6A, HK	
Q803		Transistor, 256000	The second second	
D301	n n HS e e			
D301 D302		Diode, 17261		
שטעע		22000,		

Ref.					Unit
No.	Part No.	Description	we have a second		Price
T.O.F.O.		Diode,	1T261		
D353		_	1T261		4
D354		Diode,	11201	3	•
		Diodo	1T243		
D501	ate of the second	Diode,	11245		•
D601		Diode,	1T22A		
D602		Diode,	1T22A		
D002		,		*	4"
D701	•	Diode,	1T22A		
D702		Diode,	1T22A		
			- contract		
D801		Diode,	1T22A		
D802		Diode,	SB-2		
D803		Diode,	HFSD-1Z		*
D804		Diode,	HFSD-1Z		: <b>@</b>
D808		Diode,	HFSD-1A		
4				*, .	
Th301	8-690-003	Thermistor,	S-90		. •
Th551	8-690-003	Thermistor,	S-90		
					٠ سر ٢
IC401	8-759-101-60	IC,	μPC-16C		
					٠
		Coils			2 1
		<u> </u>	· · · · · · · · · · · · · · · · · · ·		*
L301	1-409-153	40.4 MHz, traj	)		
L301	1-409-150	33.4 MHz, trap			
L305	1-407-184	3.3 uH. micro	inductor		
L305	1-407-177	470 uH. micro	inductor		4
L307	1-407-177	470 uH micro	inductor		
L308	1-407-177	470 µH, micro	inductor		
L360	1-407-184	3.3 µH, micro	inductor		
L361	1-407-184	3.3 µH, micro			,
707	1-407-104	3.3 /2		1.1	
L501	1-407-178	1 μH, micro in	nductor		
L502	1-407-159	2 5 -77	1 - 1 tox		
L504	1-407-174	270 uH. micro	inductor		
L505	1-407-173	220 µH. micro	inductor inductor		
1000	7 10. 7.2				
L701	1-421-127	Choke Coil, v	ertical output -		
J. 7 - C _ L					
L801	1-421-013	25 μH, micro	inductor		
	- TOTAL				

4/16 (TV9-90UM) (TV9-9-3)

			•	
	Ref.	Part No.	Description	Unit <u>Price</u>
	L802 L803 L804 L805 L806	1-407-366 1-407-366 1-407-220 1-459-043 1-407-175	1.7 µH, coil, RF choke	
	L901	1-421-142	Choke Coil, filter	**
	DY	1-451-056-11	Deflection Yoke Ass'y	
			Transformers	
•	T301 T302 T303 T351 T352 T353 T354 T355 T356 T357	1-403-508 1-403-508 1-403-510 1-403-534 1-403-535 1-403-536 1-403-536 1-403-537 1-403-538 1-403-364-11 1-403-364-21	Transformer, first video i-f Transformer, second video i-f Transformer, third video i-f Transformer, first sound i-f Transformer, second sound i-f Transformer, third sound i-f Transformer, fourth sound i-f Transformer, fifth sound i-f Transformer, sixth sound i-f Transformer, seventh sound i-f Transformer, seventh sound i-f Transformer, seventh sound i-f	
	T501	1-403-354	SIF Input	
	т701	1-435-008	Vertical Blocking Osc	
	T801 T802 T803 T805	1-435-034 1-437-019 1-453-021-128 1-459-043	Horizontal Blocking Osc	
	Т901	1-441-531 1-403-351 1-403-353 1-403-366	Power Trans  AGC Detector Block  Video Detector Block  AM SIF Detector Block	

Ref.	Part No.	Description	13 - 13 7 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	and the second of	Unit Price
	ske en en en e	Capacitor	s.	S	×
	the state of the s		Tarrell of the state of	5 P	· ·
	· · · · · · · · · · · · · · · · · · ·	Capacitors at	re +100 -0 %, 50 WV	and	14.
			ss otherwise specifi		5 m 61
	- B - W - W - W - W - W	* * * * *	mm the State		•
C301	1-101-552		.2 pF 50 WV, cera	mic	a C
C302	1-101-552	3.5 pF ±0.	.2 pF 50 WV, cera	mic	Ð
		0.01 μF			\$40 J.F
C305		- •	· arabasy liliana		. 41
C306	1-101-004		4		1 2 C
C308	1-101-004	- • p	. #		. · ·
C309	1-101-004	m			**
C310	1-101-004	0.01 pF			21 <del>5</del> 4
C311	1-101-004				11
C313	1-101-004	0.01 μF		-1-4	
C314	1-121-413	100 μF +10	00 -10 % 6.3 WV,	electrolytic-	·
C315	1-101-004	0.01 μF			
C316	1-121-482	33° μF +10	00 -10 % 6.3 WV,	electrolytic-	1-49-50
C317	1-101-837	0.5 pF $\pm 0$ .	2 pF 50 WV, cer	amic	r
C319	1-101-004	0.01 μF			
C324	1-101-004			2	* .
C325 *	1-121-471	10 μF +10	00 -10 % 16 WV, e	lectrolytic -	•
C326		$200  \mu F + 20$	% 10 WV, e	lectrolytic -	· ·
C327	1-121-338	$47  \mu F$ $+10$	0 -10 % 16 WV, e	lectrolytic -	J* .
C328	1-101-004	0.01 μF			
C329	1-121-341	220 μF +10	0 -10 % 16 WV, e	lectrolytic -	
C330	1-101-004	0.01 µF			
C331	1-101-004	0.01 μF			
C332		·k	•		
C333	1-121-485	33 $\mu$ F +10	0 -10 % 16 WV,	electrolytic-	F2 7
C360	1-101-004	0.01 μF		******	4
C361	1-101-004	0.01 $\mu F$		-44	
C362	1-101-004	0.01 μF			F1 1
C364	1-101-004	0.01 µF	A		. * *
C365	1-101-004	0.01 μF	-,44,4-22-2		<u>:</u>
	1-101-004	0.01 μF	1924-20		* *
	1-101-004	0.01 µF	122@_2@ 22@_2&E		
C369	1-101-004	0.01 µF		-444-41-41	$i \not \in \mathbb{R}$
	1-121-482	33 uF +10	0 -10 % 6.3 WV.	electrolytic-	ŧ
C371	1-101-004	0.01 µF			
C373	1-101-004	0.01 μF	24		
C376	1-101-004	0.01 μF			
C377	1-101-004	0.01 pF		-4	

(TV9-9-3)

```
Unit
Ref.
                   Description
                                                        Price
No.
      Part No.
                   0.01 µF
C378
      1-101-004
                   0.01 µF -----
C379
      1-101-004
                   0.01 uF -----
C381
      1-101-004
                   0.01 µF -----
C382
      1-101-004
                   0.01 µF -----
      1-101-004
C383
                   0.01 µF
C385
      1-101-004
                   0.01 µF -----
C386
      1-101-004
                          +100 -10 % 6.3 WV, electrolytic-
                   33 µF
C387
      1-121-482
                   0.01 µF
C388
      1-101-004
                           +0.2 pF
                                      50 WV, ceramic -----
C389
      1-101-584
                   2 pF
                   0.01 µF
      1-101-004
C391
                   3.5 pF \pm 0.2 pF \pm 50 WV, ceramic -----
C392
      1-101-552
                   0.01 μF -----
C396
      1-101-004
                   0.01 µF -----
C397
      1-101-004
                           +100 -10 %
                                      16 WV, electrolytic -
C398
      1-121-341
                   220 uF
                   10 uF
                           +20 %
                                      50 WV, electrolytic -
C399
      1-121-716.
                   0.01 µF
C401
      1-101-004
                   0.01 µF -----
C402
      1-101-004
                   0.01 µF -----
C403
      1-101-004
                   0.01 µF
C404
      1-101-004
                   0.002 µF -----
      1-101-002
C407
                           <u>+</u>20 % 50 WV, ceramic -----
                   0.005 µF
C408
      1-101-058
                           +100 -10 %
                                      6.3 W, electrolytic-
      1-121-729
                   10 µF
C409
                                      16 WV, electrolytic -
                           +100 -10 %
C501
      1-121-471
                   10 µF
                   60 pF
                                      50 WV, ceramic -----
C502
      1-101-583
                           +5 %
C503
      1-101-583
                   60 pF
                           +5 %
                                      50 WV, ceramic -----
                           +100 -10 %
                                      16 WV, electrolytic -
                   47 µF
C504
      1-121-338
                           +100 -10 %
                                     16 WV, electrolytic -
C505
      1-121-338
                   47 µF
                                      100 WV, mylar -----
                   0.001 uF
                           +10 %
C506
      1-105-701-12
      1-121-356
                   100 µF
                           +100 -10 %
                                    16 WV, electrolytic -
C507
                                      150 WV, paper -----
                   0.2 µF
                           +20 %
C508
      1-113-124
                   4.7 µF
                           +100 -10 %
                                      160 WV, electrolytic-
C509
      1-121-246
                                      500 WV, paper -----
      1-113-122
                   0.05 µF
                           +20 %
C510
                                      500 WV, paper -----
                           +20 %
      1-113-122
                   0.05~\mu F
C511
                                      50 WV, ceramic -----
                   62 pF
                           <u>+</u>5 %
C512
      1-102-849
                   150 pF
                           +5 %
                                      50 WV, ceramic -----
      1-102-888
C513
                           +100 -10 %
                                      16 WV, electrolytic -
      1-121-471
                   10 μF
C551
                   470 µF
                           +100 -10 %
                                      16 WV, electrolytic -
C552
      1-121-732
                           +100 -10 %
                                      16 WV, electrolytic -
C553
      1-121-341
                   220 µF
                   33 µF
                           +100 -10 %
                                      16 WV, electrolytic -
     1-121-485
C554
                  47 µF
                           +100 -10 %
                                      16 WV, electrolytic -
C555
      1-121-555
```

```
Ref.
                                                                                  Unit
     No.
              Part No.
                                Description
                                                                                  Price
     C556
              1-101-005
                                0.02 uF -----
     C557
              1-105-685-12
                                0.1 µF
                                          +10 %
                                                         50 WV, mylar ----
     C558
              1-101-005
                                0.02 µF
     C601
              1-127-021
                                0.3 \mu F
                                          +20 %
                                                         10 WV, electrolytic
                                                                 (alox) -----
     C602
              1-127-025
                                3 uF
                                                         10 WV, electrolytic
                                                                 (alox) -----
     C603
              1-121-464
                               4.7 uf
                                          +100 -10 %
                                                         25 WV, electrolytic -
     C604
              1-121-338
                                47 µF
                                          +100 -10 %
                                                         16 WV, electrolytic -
     C605
              1-105-713-12
                                0.01 µF
                                          ±10 %
                                                         100 WV, mylar -----
                                0.01~\mu\text{F}
     C606
              1-105-713-12
                                          +10 %
                                                         100 WV, mylar -----
     C607
              1-105-709-12
                                0.0047 pF
                                          +10 %
                                                         100 WV, mylar -----
     C608
              1-105-715-12
                                0.015 µF
                                          +10 %
                                                         100 WV, mylar -----
     C609
              1-127-025
                                3 \mu F
                                          +20 %
                                                         10 WV, electrolytic
                                                                (alox) -----
     C610
             1-105-721-12
                               0.047 µF
                                          +10 %
                                                         100 WV, mylar -----
     C611
             1-121-458
                                3.3 µF
                                          +150 -10 %
                                                         50 WV, electrolytic -
     C612
             1-101-424
                               500 pF
                                          +20 %
                                                         250 WV, ceramic -----
     C613
                               0.0068 \mu F + 10 \%
             1-105-711-12
                                                         100 WV, mylar -----
     C701
             1-127-232
                               4.7 µF
                                          +20 %
                                                         25 WV, electrolytic
                                                                (alox) -----
     C702
             1-121-732
                               470 µF
                                          +100 -10 %
                                                         16 WV, electrolytic -
     C703
             1-131-116
                               10 µF
                                          +20 %
                                                         15 WV, tantalum ----
     C704
             1-121-403
                               33 µF
                                          +100 -10 %
                                                         16 WV, electrolytic -
     C705
             1-127-025
                               3.3 µF
                                          +20 %
                                                         10 WV, electrolytic
                                                                (alox) -----
     C706
             1-121-414
                               100 µF
                                                         10 WV, electrolytic -
                                          +100 -10 %
     C707
             1-105-727-12
                               0.15 µF
                                          +10 %
                                                         100 WV, mylar -----
     C801
             1-105-715-12
                               0.015 \, \mu F + 10 \, \%
                                                         100 WV, mylar -----
     C802
             1-105-711-12
                               0.0068 \mu F + 10 \%
                                                         100 WV, mylar -----
     C804
             1-101-007
                               0.05 µF -----
     C805
             1-129-163
                               0.022 µF
                                          +5 %
                                                         50 WV, styro1 -----
                                          +10 %
     C806
             1-105-717-12
                               0.022 \mu F
                                                        100 WV, mylar -----
*C807,808
                               0.015 µF
             1-105-715-12
                                          +10 %
                                                        100 WV, mylar -----
*C807,808
                               0.0015 \mu F + 10 \%
             1-105-703-12
                                                        100 WV, mylar -----
*C807,808
             1-105-705-12
                               0.0022 \mu F + 10 \%
                                                        100 WV, mylar -----
*C807,808
             1-105-707-12
                               0.0033 \mu F + 10 \%
                                                        100 WV, mylar -----
*C807,808
             1-105-709-12
                               0.0047 \muF \pm10 %
                                                        100 WV, mylar -----
*C807,808
             1-105-711-12
                               0.0068 μF ±10 %
                                                        100 WV, mylar -----
*C807,808
             1-105-713-12
                               0.01 µF
                                          +10 %
                                                        100 WV, mylar -----
             * Mark to be selected.
```

```
Ref.
                                                                             Unit
     No.
             Part No.
                              Description
                                                                             Price
                                                    100 WV, mylar -----
     C809 1-105-725-12 0.1 \muF \pm 10\% 100 WV, mylar ----- C810 1-101-821 0.002 \muF \pm 10\% 500 WV, ceramic ----
             1-101-845
                              0.001 μF +100 -0 %
                                                     500 WV, ceramic ----
     C814
C812 1-105-466-12 *C811,813 1-105-461-12
                                              600 WV, mylar -----
                              0.0068 \mu F + 10 \%
                              0.001 µF
                                        +10 %
                                                      600 WV, mylar -----
           1-105-462-12 0.0015 \mu F \pm 10 %
*C811,813
                                                      600 WV, mylar -----
*C811,813 1-105-463-12
                              0.0022 \mu F \pm 10 \%
                                                      600 WV, mylar -----
*C811,813 1-105-464-12
                            _{\rm a} 0.0033 \muF \pm 10 %
                                                      600 WV, mylar ----
*C811,813 1-105-465-12 0.0047 \muF \pm 10 %
                                                    600 WV, mylar -----
*C811,813 1-105-466-12
                              0.0068 \mu F + 10 \%
                                                      600 WV, mylar -----
    C815 1-101-845
                                                      500 WV, ceramic ----
                              0.001 µF
                                       +100 -0 %
                                        <u>+</u>10 %
     C816 1-129-496
                                                     100 WV, styrol -----
                              1.8 µF
    C817 1-129-497
                                        +10 %
                                                      100 WV, styrol -----
                              1 µF
                                       +100 -0 %
    C818 1-101-845
                             0.001 µF
                                                      500 WV, ceramic ----
     C819 1-121-703
                                        +100 -10 %
                              100 µF
                                                      50 WV, electrolytic -
                        - (10) 100 μF
    C820 1-121-703.
                                       +100 -10 %
                                                      50 WV, electrolytic -
                              0.015 µF
                                                      200 WV, mylar -----
    C821 1-105-755-12
                                       +10 %
    C822 1-113-122
                       "/*A 15
                                                     500 WV, paper -----
                             0.05 µF
                                        +20 %
    C823 1-105-749-12
                             0.0047 \mu F + 10 \%
                                                      200 WV, mylar -----
                                       +100 -0 %
                                                      500 WV, ceramic ----
    C824
             1-101-845
                              0.001 µF
           1-105-465-12
                             0.0047 \mu F + 10 \%
                                                      600 WV, mylar -----
    C901 1-109-015
                            2000 pF - <u>+10</u> %
                                                      500 WV, mica -----
    C902 1-109-015
                            2000 pF
                                        +10 %
                                                     500 WV, mica -----
                         184
    C903 1-121-023
                                                     15 WV, electrolytic -
                             4000 µF
                                       +30 -10 %
                                                     12 WV, electrolytic -
15 WV, electrolytic -
    C904 1-119-101
                            100 µF
    C905 1-121-023
                              4000 uF
         * Mark to be selected.
```

1

7 4

. Will All Miles D

ه يود ۱۸ مود

112 44 17

Profession and the second

28176 17 17 17 18 28176 17 18 17 18

181 8 , W 100 C

\* sal it is the 150. 1.1.m 1/ 001

----- 121 M. A. 161

---- 163 m 18 34 - commercial called the cold

Ref.			Unit
No.	Part No.	Description	Price
		Resistors	
		· · · · · · · · · · · · · · · · · · ·	** **
		Resistors are ±5 %, ERD14V, and carbon	
		unless otherwise specified.	
			:
R151	1-246-653	150 Ω ERD14T, carbon	
	- ,		
R301	1-246-637	33 Ω ERD14T, carbon	: • <del></del>
R302	1-248-649	100 Ω	• •
R303	1-248-659	270 Ω	
*R304	1-204-154	〒 f 7 - 57 - 17 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -	
*R304	1-203-182	510 $\Omega$ RD1/16L, carbon	· <b>-</b>
*R304	1-204-195	2 kΩ RD1/16L, carbon	
R305	1-246-666	510 Ω ERD14T, carbon	
R306	1-246-649	100 Ω ERD14T, carbon	
R307	1-248-659	270 Ω ERD14T, carbon	
*R308	1-203-469	6.2 k $\Omega$ RD1/16L, carbon	
*R308	1-203-189	8.2 kΩ RD1/16L, carbon	
*R308	1-203-199	10 kΩ RD1/16L, carbon	_
*R308	1-203-190	20 kΩ RD1/16L, carbon	_
R309	1-248-653	150 Ω	· <del>-</del>
	, , , , , , , , , , , , , , , , , , , ,	5.6 kΩ	
R310	1-248-691	1.2 kΩ	· <del>-</del>
R311	1-248-675	150 Ω	
R312	1-248-653		
*R313	1-203-469	6.2 kΩ RD1/16L, carbon	· <del>-</del>
*R313	1-203-189	8.2 kΩ RD1/16L, carbon	-
*R313	1-203-190	10 kΩ RD1/16L, carbon	-
*R313	1-203-699	20 kΩ RD1/16L, carbon	-
R314	1-248-646	3.9 kΩ	-
R315	1-248-687		
R316	1-248-696	9.1 kΩ	-
*R317	1-248-688	4.7 kΩ	4
*R317	1-248-689	4./ K!!	•
*R317	1-248-690	5.1 kΩ	
R318	1-248-676	1.3 kΩ	
R319	1-248-655	180 Ω	- <del>-</del>
R320	1-248-657	220 0	
R321	1-248-667	560 Ω	
R322	1-248-641	47 Ω	·-
*R323	1-246-703	18 kΩ ERD14T, carbon	<del></del>
*R323	1-246-704	20 kΩ ERD14T, carbon	
*R323	1-246-705	22 kΩ ERD14T, carbon	
		* * *	

\* Mark to be selected.

Ref.					Unit
No.	Part No.	Description	<u>on</u>	69	Price
700/	1 0/6 601	0 0 10	INDO 1 COLUMN TO THE PARTY OF T		
R324	1-246-681	2.2 kΩ	ERD14T, carbon ERD14T, carbon		
R351	1-246-649	100 Ω	ERD141, carbon		
R352	1-248-673	1 kΩ	ERD14T, carbon		
R353	1-246-660	300 Ω	DD1/161		
*R354	1-203-469	6.2 kΩ	RD1/16L, carbon		
*R354	1-203-189	8.2 kΩ	RD1/16L, carbon RD1/16L, carbon		
*R354	1-203-190	10 kΩ	RDI/16L, carbon		
*R354	1-203-699	20 kΩ	RD1/16L, carbon		
R355	1-248-660	300 0			
R356	1-248-695	8.2 KΩ			
R357	1-248-684	3 kΩ			
R358	1-248-660	6			
*R359	1-204-195	2 kΩ	RD1/16L, carbon		
*R359	1-203-451	3 kΩ	RD1/16L, carbon		•
*R359	1-204-345	5.1 kΩ	RD1/16L, carbon		
R360	1-248-660	300 Ω			
R361	1-248-696	9.1 kΩ			*
R362	1-248-675				
R363	1-248-651	120 Ω			
*R364	1-203-469	6.2 kΩ	RD1/16L, carbon		
*R364	1-203-189	8.2 kΩ	RD1/16L, carbon		
*R364	1-203-190	10 kΩ	RD1/16L, carbon		
*R364	1-203-699	20 kΩ	RD1/16L, carbon		
R365	1-248-653	150 Ω			
R366	1-246-673	$1 k\Omega$	ERD14T, carbon		
R367	1-248-649				
R368	1-248-660	300 Ω			
*R369	1-204-154	510 Ω	RD1/16L, carbon		. 4
*R369	1-203-182	1 kΩ	RD1/16L, carbon		A c
*R369	1-204-195	2 kΩ	RD1/16L, carbon		v.
R370	1-246-660	300 Ω	ERD14T, carbon		
R371	1-246-695	8.2 kΩ	ERD14T, carbon		
R372	1-248-684				
R373	1-248-660				
*R374	1-203-856	150 Ω	RD1/16L, carbon		
*R374	1-204-534	300 Ω	RD1/16T. carbon		*
*R374	1-204-154	510 Ω	RD1/16L, carbon		
R375	1-248-660	300 0			
R376	1-248-696	9.1 kΩ			,
R377	1-248-675	1 2 k0			
R378	1-248-651	120 Ω			

\* Mark to be selected.

Ref.			Unit
No.	Part No.	Description	Price
*R379	1-204-195	2 kΩ RD1/16L, carbon	
*R379	1-203-451	3 kΩ RD1/16L, carbon	
*R379	1-204-345	5.1 kΩ RD1/16L, carbon	
R380	1-248-653	150 Ω	
*R381	1-204-195	2 kΩ RD1/16L, carbon	1.1
*R381	1-203-451	3 kΩ RD1/16L, carbon	
*R381	1-204-345	5.1 kΩ RDI/16L, carbon	
R382	1-246-641	47 Ω ERD14T, carbon	. 19
R383	1-246-704	20 kΩ ERD14T, carbon	48
R384	1-248-703	18 kΩ	J
R385	1-248-699	12 kΩ	147.8
21303	2 2 10 055	The prop	* * * * * * * * * * * * * * * * * * * *
R401	1-248-656	200 Ω	
R402	1-246-688	4.3 kΩ ERD14T, carbon	4 - 4
R404	1-202-018	3.9 k $\Omega$ RC1/8, composition	
R405	1-248-661	330 Ω	
R40J	1 240 001	550 % **	*
R501	1-248-714	51 kΩ	
R502	1-248-710	36 kΩ ===================================	
R503	1-248-663	390 Ω	
R504	1-248-663	390 0	
R505	1-248-673	1 kΩ	
R507	1-248-708	30 kū	
R508	1-248-693	6.8 kΩ	
R509	a de estado de		
R510	1-248-643	56 Ω	
R511	1-248-673	$1^{-k}$ $\alpha$ -and $\alpha$	· · ·
R512	1-244-891	5.6 kΩ RD12T, carbon	
R513	1-244-921	100 kΩ RD12T, carbon	i
R514	1-248-697	$10~\mathrm{k}\bar{\Omega}$	
R515	1-248-732	300 κΩ	
R551	1-246-715	56 kΩ ERD14T, carbon	
R552	1-246-673	1 kΩ ERD14T, carbon	, ,
R553	1-248-697	10 kΩ	
R554	1-248-697	10 kΩ	
R555	1-248-679	1.8 kΩ	
R556	1-248-612	$\hat{3}$ $\hat{\mathbf{\Omega}}$	
R557	1-248-693	6.8 kΩ	
R558	1-248-675	$1.2 \text{ k}\Omega$ 11011222221	
R559	1-248-641	47 Ω	.*
R560	1-248-655	180 Ω	
R561	1-248-656	$200  \hat{\Omega}$	
1001	1 240 000		

\* Mark to be selected.

Ref.					Unit
No ·	Part No.	Description	A Commence of the Commence of	43 F 3 7 1+M	Price
ent mandel at	4 040 655			the room seems against the seems	- gulg date
R562	.1-248-675	1.2 $k\Omega$			w. 4
R563	1-248-612	3 Qeavar			1 7/3
R564	1-248-618	5 · t <sub>e</sub> Ω -=		777777	. Ø
R565	1-246-631	$18 \Omega$ ERD14T, ca	arbon 77	77782857377	
R566	1-246-655	$\Omega$ ERD14T, ca	irbon		12013
m ( 0 t	William to the Act of the part of the same purposes.	51 Ω 330 Ω 10 kΩ 470 kΩ 3 kΩ	1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -	1701663-1	84, 38
R601	1-248-642	$\sim .51$ $\Omega_{m}$ $= $			814
R602	1-248-661	$0.330$ $\Omega_{\rm max}$			1,36%
R603	1-248-697	10 kΩ			4 1 ·
R604	1-248-737	. 4/0 kΩ			± * :
R605	1-248-684	.3 kΩ			g <sup>2</sup>
R606	1-248-69/	10 kΩ			
R607	1-248-701	15 kΩ	;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;		
R608	1-248-712	43 kΩ		778773277	
R609	1-248-656	200 Ω 2.4 kΩ 10 kΩ		- 87m-561-7	,
R610	1-248-682	2.4 kΩ		193-84:11	
R611	1-248-69/	10 kΩ			
R612	1-248-686	$3.6 \text{ k}\Omega$ $2 \text{ k}\Omega$ RD1P, carb			: 27
R613		$2 k\Omega$ RD1P, carb	on value -		77 h ju
R614	1-248-680	2. KΩ			:
R615	1=248=666	510 .Ω. ==================================	:0-068;		1. 1 t + 10
R616	1=248=701	.15 .kΩ. ==================================	:===		8 N. 19
R617	1=248=680	2. kΩ			. +,3
R618	1=248=704	20 kΩ 360 Ω	3.3		\$ 1,7 kg
R619	1-248-662	360 \$2			<b>V</b> (1)2* 1
R620	1-248-625	10 $\Omega$ 2 WV, meta		TERMINATE TO	, 12,
R621	1=206-05/	150 $\Omega$ 2 WV, meta	T oxiqe		12 9
D 701	The end of the same of the same of the same	300 Ω 227	red my f		24.
R701	1-248-660	300 Ω 4.3 kΩ			2.5
R702	1-248-688	4.3. kΩ . = = = = = = = = = =	45 - 01	17 484	. TH. K
R703	1-248-6//	1.5 kΩ	.144104811111		3 . 74
R704	1-248-625	10 Ω			»/ ·
R705	1=248=688.	4.3 kΩ			4
R706	1-248-690	5.1 kΩ			. "
R707	1-246-703	18 kΩ ERD14T, ca	rbon		9,19
R708	1-248-680	2.kΩ			1 - 1 5:
R709	1 2/0 600	2 kQ ===================================			5 # 14 %
R710	1-248-688	4.3 kΩ ===================================	-57-2		1.1.4
*R711	1 2/0 (72	820 Ω	23		3 1 - 12
*R711	1-248=6/3	1.2.10		11141414141	$\hat{\mathcal{L}} = \mathcal{A}$
*R711	1 2/0 (77	1.4 KW ===================================	FTATORF	TERMINIST!	1000
*R711	1-248-6//	1 .2 kΩ	77700	888+337-7	· 4. **
	* Mark to be se			Contract	

Ref.			Unit
No.	Part No.	Description	Price
14 Taranta (14 A		10 e	
*R711	1-248-679	1.8 kΩ	
*R711	1-248-680	2 kΩ	
*R711	1-248-681	2.2 kΩ	
*R711	1-248-682	2.2 kΩ	
R712	1-248-665	470 Ω	
R713	1-207-073	3 Ω RW1/2RL, wire wound	
R714	1-248-661	330 Ω	
R715			
R716	1-248-697	10 kΩ	
		4.3 kΩ	
R801	1-248-688	4.3 kΩ	
R802	1-248-673	$1 \text{ k}\Omega$	
R803	1-248-666		
R804	1-248-000	510 0	
R805	1-248-660	300 Ω	
R806	1-207-092	8.2 Ω RW1/2RL, wire wound	
R807	1-248-691	5.6 kQ	
R808	1 0/0 650	2/0 0	
R809	1-248-673	1 k0	
R810	1-248-621	100 k $\Omega$ RC1/2, composition	
R811	1-202-621	100 k $\Omega$ RC1/2, composition	
R812	1-246-704	20 kΩ ERD14T, carbon	
R813	1-207-094	11 Ω RW1/2RL, wire wound	
R901	1-207-054	3.9 $\Omega$ RW3L, wire wound	
	And the first service of the first		
VR301	1-221-326	500 $\Omega$ -B, adjustable (AGC)	
	and the second of the second o		
VR501	1-221-709	1 kΩ-E, variable (contrast)	
VR502	1-221-429	250 k $\Omega$ -B, variable (brightness)	
VR551	1-222-271	5 k $\Omega$ -D, variable (sound)	
VR601	1-221-297	10 kΩ-B, variable (H. hold)	
VR602	1-221-390	$3 k\Omega$ -B, variable (H. freq.) 819 lines	
VR603	1-221-390	3 k $\Omega$ -B, variable (H. freq.) 625 lines	
VR701	1-221-403	2 kΩ-B, variable (V. hold)	
VR702	1-221-389	$5 k\Omega$ -B, variable (V. hieg)	
VR703	1-221-390	3 k $\Omega$ -B, variable (V. 1in)	


<sup>\*</sup> Mark to be selected.


Ref.	Part No.	Description	Unit <u>Price</u>
		Miscellaneous	
•	1-231-089-11 1-509-344 1-506-108	AM SIF Filter Block Socket, voltage changing Terminal Pin, SV	
	1-508-044-21 1-507-134-21 1-509-091-12	Plug, 9 pin	
	1-526-083-42 1-514-593	Socket, picture tube	at .
CRT	1-536-149 1-536-171 8-731-209-99	Terminal Strips, 2-L Terminal Strips, L-7-L Picture Tube (230DB4)	
DFM-1	1-417-027 1-502-169 1-501-092-128	U.V. Tuner Separator with High Pass Filter SpeakerAntenna Ass'y, telescopic	* .
J901	1-507-174-22 1-508-082-23	Jack, 2 P earphone	Y
Se901 S902 F901	1-531-027 1-513-216-14 1-532-201-12	Selenium Rectifier	. (C)
F902	1-532-204 1-506-198 1-534-379-51 1-534-587-11 1-536-144	Fuse, thermal  Fuse, 2 A  DC2p Plug with Fuse Holder  Cable, IF output  Cord, AC power  Terminal Strips, L-1	
P901	1-536-192 1-536-249	Terminal Strips, 2-L-2 Terminal, 4 pole power	

		Unit	
Part No.	Description		
	IV. CARTONS & ACCESSORIES		
4-012-817	Packing Carton		
4-012-816	Master Carton (2 sets)		
4-012-818	Cushion, right		
4-012-819	Cushion, left		
4-011-018	Polyethylene Bag		
X-40128-06	Card Ass'y		
X-44900-03	Polishing Cloth in Polyethylene Bag		
4-495-234-11	Instruction Manual		
1-504-034-22	Earphone (ME-20A)		
4-004-143	Serial Number Label		
3-701-161	Polyethylene Bag, accessories		

(TV9-9-3)


#### EXTERNAL VIEW








#### MAJOR PARTS LOCATION






#### DISASSEMBLY

#### Rear Cabinet Removal

1. Pull off the four control knobs and UHF dial and UHF dial knob (1), 2 in Fig. 1).

2. Remove the two screws (3,4 in Fig. 1). Fig. 2).

Fig. 2






Fig. 3



#### **Deflection Circuit Board Removal**

- 1. Remove the two screws (1), 2 in Fig. 4).
- 2. Unsolder the braided wire (3 in Fig. 4).
- 3. Pull off the anode cap and picture tube socket (1), (2) in Fig. 5).
- 4. Disconnect the 3-pole connector and 9-pole connector (3), 4 in Fig. 5).
- 5. Unsolder the three black leads ( 6 in Fig. 5).
- 6. Unsolder a brown lead ( 5 in Fig. 5).
- 7. Unsolder the two shielded cables ( 6 , 10 in Fig. 6).
  - 8. Unsolder the eight leads ( ① , ② , ③ , ④ , ⑤ , ⑦ , ⑧ , ⑨ , in Fig. 6).




Fig. 4






Fig. 5




\* ..... Soldered on the conductor side.

Fig. 6





- 1. Remove the two screws ( 7 in Fig. 5).
- 2. Unsolder the eight leads ( A , B , C , D , E , F , G , H in Fig. 6).




#### Signal Circuit Board Removal

- 1. Take out the EF block.
- 2. Pull off the channel knob, fine tuning knob and ON/VOL control knob(3, 4, 5 in Fig. 7).
- 3. Remove the two screws (1), 2 in Fig. 7).
- 4. Remove a screw (1) in Fig. 8).
- 5. Unsolder a brown lead (2 in Fig. 9).
- 6. Unsolder a shielded cable (3 in Fig. 9).
- 7. Remove the two screws (1) in Fig. 9).
- 8. Unsolder the all leads in Fig. 10.







\*..... Soldered on the conductor side

Fig. 10

#### FM SIF Block Removal

- 1. Take out BC block.
- 2. Remove the two screws (1 in Fig. 11).
- 3. Unsolder the two leads and the two shielded cables in Fig. 12.







Fig. 12



#### UHF Tuner Removal

- 1. Take out the BC block.
- 2. Remove a nut ( ② in Fig. 13).
- 3. Disconnect a phono plug in Fig. 14.
- 4. Unsolder a coaxial cable, and a orange lead (1), 2 in Fig. 14).









#### VHF Tuner Removal

- 1. Take out the BC block.
- 2. Remove a screw (1 in Fig. 13).
- 3. Unsolder a coaxial cable ( ② in Fig. 15).
- 4. Remove the three screws ( ① in Fig. 15).
- 5. Unsolder the three coaxial cables (1) in Fig. 16).
- 6. Unsolder a brown lead (2 in Fig. 16).
- 7. Remove the three screws (3 in Fig. 16).










Fig. 17

#### Picture Tube Removal

1. Remove the four screws ( ① , ② in Fig. 18).

#### Speaker Removal

1. Remove a screw (3 in Fig. 18).




Fig. 18

### ADJUSTMENTS PROCEDURE

#### VIF Adjustments

#### Pre-alignment Procedures

- Set the channel selector to a highest inactive channel in the area.
- 2. Remove the coaxial cable from the RF input terminal of tuner.
- 3. Check the 12V line.
- 4. Connect a VOM to AGC input terminal of tuner.
- 5. Set the push switch button to CCIR (625 lines) position.
- 6. Set a resistor R323 (18k 20k ohms) for a reading of 1.25 1.35 volts. (See Fig. 19).
- 7. Disconnect the VOM.

## VIF Response Curve Alignment Procedures

- 1. Connect a signal generator to the test point of tuner through a 0.01  $\mu F$  capacitor ( (A) in Fig. 19).
- Connect a scope to the VIF output terminal (VIDEO OUT) through a noise filter consisting of a 10k-ohm resistor and 200pF capacitor ( B in Fig. 19).
- 3. Set the signal generator to 40.4 MHz with 1 kHz AM modulation.
- 4. Adjust a coil L301 for obtaining minimum modulated waveform on the scope.
- 5. Reset the signal generator to 33.4 MHz with 1 kHz AM modulation.


## TV9-90UM

- Adjust a coil L302 for obtaining minimum modulated waveform on the scope.
- Make the adjustments specified in the following Table 1
- 8. Disconnect the signal generator from the test point.
- 9. Connect the sweep/marker generator to the test point (© in Fig. 19).
- 10. Connect a rheostat (10k-ohm) to the point indicated with ① in Fig. 19.
- 11. Connect a VOM across a resistor R303 ( © in Fig. 19).

- 12. Adjust the rheostat for a reading of approx. 1.5 volts on the VOM.
- 13. Disconnect the VOM.
- 14. Adjust the output level of sweep generator to obtain a 1.5 Vp-p VIF response curve on the scope.
- 15. Readjust T301, T302 and T303 to obtain the VIF response curve as shown in Fig. 20.
- 16. Adjust L207 in the tuner when satisfactory VIF response curve is not obtained by foregoing procedures ( ) in Fig. 19).
- 17. Repeat steps from 1 to 15.

TABLE 1 VIF ADJUSTMENTS

Frequency (MHz) with 1 kHz AM modulation	Adjust	Remarks
36.8	T301	Adjust T301 for obtaining maximum modulated waveform on the scope.
36.8	Т302	Same as above.
35.4	Т303	Same as above.





#### SIF Adjustments

Unsolder the VIF INPUT coaxial cable first. Remove the SIF and VIF shield covers. Equipment setup is shown in Fig. 21.

Items	<b>Equipment Connection</b>	Adjust	Remarks
T501 T402 T403	Signal Generator	T501 T402 (pink core)	Adjust for maximum indication on the VOM.
	VOM ® Range: 0.5V or 1.5V dc	T403 (blue core)	Adjust for minimum modulated waveform.
•	Scope ©		
Confirmation of S curve	Sweep/marker generator (A) Freq.: 5.5 MHz	T501 T402 (pink core) T403 (blue core)	Turn up sweep generator output to produce an S curve.  If the S curve is not symmetrical
	Scope ©		as illustrated in Fig. 22, adjust T501, T402 and T403 for best result.




Fig. 21

#### **AM-SIF Adjustments**

#### 46.5 MHz AM-SIF response curve adjustments

- 1. Set the push switch button to F & B (819 lines).
- 2. Unsolder the tuner output lead from signal circuit board (BC).





Fig. 22

- 3. Connect a dummy resistor (5k-ohm) across the scope input terminal through a noise filter consisting of a 10k-ohm resistor and a 200pF capacitor as shown in Fig. 23.
- Connect a sweep/marker generator to the AM-SIF input to the signal circuit board (BC) through a 0.01µF capacitor as shown in Fig. 23.
- 5. Make the adjustments specified in the following table.

Equipment	Connection	Frequency	Adjust	Indication	
Signal generator	AM-SIF input (A in Fig. 23)	46.5 MHz (with 1 kHz AM)	T351 T352 T353	For maximum modulated waveform on the scope.	
Scope	AM-SIF output (® in Fig. 23)				
Sweep generator Marker generator	AM-SIF input (© in Fig. 23)			Set the sweep generator switch on. Confirm that the AM-SIF	
Scope	AM-SIF output (® in Fig. 23).			(46.5 MHz) response curve will appear on the scope (See Fig. 24).	

## V9-90UM



#### 27.5 MHz & 32.6 MHz AM-SIF response curve adjustments

- 1. Set the push switch button to F & B (625 lines).
- 2. Unsolder the tuner output lead from signal circuit board (BC).
- 3. Connect a dummy resistor (5k-ohm) across the scope input terminal through a noise filter consisting of a 10k-ohm resistor and a 200pF capacitor as shown in Fig. 25.
- 4. Connect a sweep/marker generator to the AM-SIF input to the signal circuit board (BC) through a 0.01 µF capacitor as shown in Fig. 25.
- 5. Adjust T354 and T355 to obtain the maximum AM-SIF response curve on the scope.
- 6. Make the adjustments specified in the following table.

Marker generator Frequency (MHz)	Adjust	Correct marker position on the response curve	Indication
27.5	T356	A (peak)	Adjust T356 and T357 to obtain the AM-SIF response curve as shown in Fig. 26.
32.6	T357	B (peak)	




Fig. 25




Fig. 26




### Deflection Circuit Adjustments

Items	Preparations	Equipment	Connection	Adjust	Remarks
Collector current of Q703 (Vert. OUT)	<ol> <li>Set the push switch button to CCIR (625 lines).</li> <li>Lock in sync.</li> <li>Check 12 V power supply.</li> <li>Unsolder a green lead which is connected to the collector of Q703.</li> </ol>	ammeter	Between the green lead and the col- lector of Q703	△ R711 (820 ~ 2.4 kohm)	for reading of 120 ~ 126 mA.
Vert. Height and Linearity	<ol> <li>Set the push switch button to CCIR (625 lines).</li> <li>Receive a test pattern for CCIR (625 lines).</li> <li>Check 12V power supply.</li> </ol>		·	VR702 & VR703	for obtaining the optimum vert. height and linearity.
Pulse-width F & B (819 lines)	<ol> <li>Set the push switch button to F &amp; B (819 lines).</li> <li>Receive a test pattern for F &amp; B (819 lines).</li> <li>Lock in sync.</li> </ol>			△C807 (0.001 - 0.01 μF)	for pulse-width of 11.5 - 12.5 \( \text{p sec.} \)  11.5 -12.5 \( \text{p sec} \)  Horizontal pulse-width
Pulse-width CCIR (625 linès)	<ol> <li>Set the push switch button to CCIR (625 lines).</li> <li>Receive a test pattern for CCIR (625 lines).</li> <li>Lock in sync.</li> </ol>			△C808 (0.001 - 0.01 μF)	for pulse-width of 12.5 - 13.5 \mu sec.  12.5 -13.5 \mu sec  Horizontal pulse-width
Horizontal Frequency F & B (819 lines)	<ol> <li>Set the push switch button to F &amp; B (819 lines)</li> <li>Receive a test pattern for F &amp; B (819 lines).</li> <li>Set the contrast and brightness controls to the optimum position.</li> </ol>			VR602	Adjust VR602 so that the number of diagonal bars are almost same for both extreme clockwise and counterclockwise settings of VR601 (H. hold).
Horizontal Frequency CCIR (625 lines)	<ol> <li>Set the push switch button to CCIR (625 lines).</li> <li>Receive a test pattern for CCIR (625 lines).</li> <li>Set the contrast and brightness controls to the optimum positions.</li> </ol>			VR603	Adjust VR603 so that the number of diagonal bars are almost same for both extreme clockwise and counterclockwise settings of VR601 (H. hold).



### TERMINAL VIEW

#### Semiconductor




E : Emitter

C : Collector

B : Base

S : Shield

Tuner circuit




★ Voltages measured from chassis to point indicated with a VOM (20k ohm/V), with no signal input.


#### MOUNTING DIAGRAM

VHF tuner circuit board

- Conductor side -



- Component side -




- ★ Voltages measured from chassis to point indicated with a VOM (20k ohm/V), with no signal input.

#### MOUNTING DIAGRAM

Signal circuit board (BC)

- Conductor side -




Symbol No.	Location		
Q301	A-4		
Q302	B-4		
Q303	B-3		
Q304	C-3		
Q305	A-3		
Q351	E-4		
Q352	E-4		
Q353	E-3		
Q354	C-4		
Q355	C-4		
Q356	C-3		
Q357	D-3		
Q501	B-3		
Q502	A-2		
Q551	B-1		
Q552	B-1		
Q553	C-1		
Q554	C-1		
D301	B-3		
D302	B-3		
D351	E-3		
D352	C-3		
D353	E-4		
D354	D-4		
Th301	A-3		
Th551	C-1		
VR301	A-3		
VR551	A-1		

 <sup>≈</sup> R304, R308, R313, R323, R354, R359, R364, R369, R374, R379, R381: Mounted on the conductor side.

<sup>\*</sup> Resistance values marked with ^ are to be selected.

<sup>★</sup> Voltages measured from chassis to point indicated with a VOM (20k ohm/V), with no signal input.

Signal circuit




- ☆ Resistance values marked with △ are to be selected.
- ☆ Voltages measured from chassis to point indicated with a VOM (20k ohm/V), with no signal input.

## MOUNTING DIAGRAM

## Signal circuit board (BC)


- Component side -



<sup>\*</sup> R304, R308, R313, R323, R354, R359, R364, R369, R374, R379, R381: Mounted on the conductor side.

Resistance values marked with  $\Delta$  are to be selected.


#### FM SIF circuit




#### MOUNTING DIAGRAM

#### FM SIF circuit board

- Conductor side -




- Component side -




- ☆ R404: Mounted on the conductor side.
- ☆ Voltages measured from chassis to point indicated with a VOM (20k ohm/V),
  with no signal input.

## MOUNTING DIAGRAM

Power supply block





## SHECMATIC DIAGRAM




## MOUNTING DIAGRAM


Power supply block









indicated with a VOM (20k ohm/V),





## SHECMATIC DIAGRAM




#### Deflection circuit


















**1.25** Vp-p (Vert.)


**f** 1.25 Vp-p (Vert.)

To EF BOARD

**6** 1V p-p (Vert.)



















60 Vp-p (Vert.)

2 Vp-p (Horiz.)

Voltages measured from chassis to point indicated with a VOM (20k ohm/V), with no signal input.

The waveforms numbers (  $A \sim O$  ) refer to the schematic diagram.

Deflection circuit



2.5 Vp-p (Horiz.)

18 Vp-p (Horiz.)

Voltages measured from chassis to point indicated with a VOM (20k ohm/V), with no signal input.

20 Vp-p (Horiz.)

15 Vp-p (Horiz.)

The waveforms numbers (  $A \sim O$  ) refer to the schematic diagram.


2 Vp-p (Horiz.)

300 Vp-p (Horiz.)

12.5 Vp-p (Horiz.)

# MOUNTING DIAGRAM

Deflection circuit board - Conductor side -





Symbol No.	Location
Symbol No.	Location
Q503	B-4
Q601	C-4
Q602	C-3
Q701	C-5
Q702	C-5
Q703	E-5
Q801	C-3
Q802	E-2
Q803	E-1
D501	C-4, 5
D601	C-3
D602	C-3
D701	C-4
D702	C-4
D801	B-3
D802	B-1
D803. D804	A-2 E-2
D804 D808	C-2
VR501	A, B-3
VR502	A, B-3
VR601	B-2
VR602 VR603	D-3 D-3
VR 701	D-3 В-2
VR701 VR702	D-4
VR702 VR703	D-4, 5
	۵ ., ۵

<sup>\*</sup> Voltages measured from chassis to point indicated with a VOM (20k ohm/V), with no signal input.

(B+IN) BRN BC

GRN GRN






Symbol No.	Location
Q503	B-4
Q601	C-4
Q602	C-3
Q701	C-5
Q702	C-5
Q703	E-5
Q801	C-3
Q802	E-2
Q803	E-1
D501	C-4, 5
D601	C-3
D602	C-3
D701	C-4
D702	C-4
D801	B-3
D802	B-1
D803.	A-2
D804	E-2
D808	C-2
VR501	A, B-3
VR502	A, B-3
VR601	B-2
VR602	D-3
VR603	D-3
VR701	B-2
VR702	D-4
VR703	D-4, 5


- △ C605, C811, C813: Mounted on the conductor side.
- $\stackrel{\circ}{\sim}$  Resistance and capacitance values marked with  $\stackrel{\wedge}{\wedge}$  are to be selected.
- \* Voltages measured from chassis to point indicated with a VOM (20k ohm/V), with no signal input.


- Component side -



- ★ C605, C811, C813: Mounted on the conductor side.
- \* Resistance and capacitance values marked with \$\triangle\$ are to be selected.

- Overall -







Symbol No.	Location
IC401	K, L-2
Q101	B-1
Q102 Q201	C-1 B-3
Q201 Q202	C-3
Q203	C-3
Q301	E-3
Q302	F-3
Q303 Q304	G-3
Q30 <del>4</del> Q305	J-3 D-2
Q351	E-1
Q352	F-1
Q353	G-1
Q354 Q355	E-2 F-2
Q356	G-2
Q357	H-2
Q501	J-3
Q502	K-3
Q503 Q551	L-3 H, J-2
Q552	J-2
Q553	J-1, 2
Q554	J-2 E-4
Q601 Q602	E-4 E-4
Q701	G-4
Q702	G-4
Q703	G, H-4
Q801	H, J-4
Q802 Q803	J-4 J-4
D101	G-1
D301	H-3
D302	H-3
D351	G-1
D352 D353	H-2 F-1
D354	F-2
D501	K, L-3
D601	E-4
D602	E-4
D701 D702	F, G-4 F, G-4, 5
D801	H-4
D802	K-4
D803	L-3
D804	L, M-4
D805 D806	L-4 L-4
D807	L-4
D808	K-4
Se901	В-4
Th 201	B-2
Th301 Th551	E-2 J-2
VR301	D-2
VR501	L, M-3
VR502	L-3
VR551 VR601	H-1 E-4
VR602	F-4
VR603	F-4
VR701	F-4
VR702 VR703	G-4 G-4
V IX / U.S	U-4

- $\Rightarrow$  Resistance and capacitance values marked with  $\triangle$  are to be selected.
- ❖ Voltages measured from chassis to point indicated with a VOM (20k ohm/V), with no signal input and the values shown in ( ) are taken with push switch set to 819.


# EXPLODE VIEW (1)




#### EXPLODED VIEW



## EXPLODE VIEW (3)



2B0655-1



When ordering replacement parts, you should use PART NUMBER listed on the Complete Spare Parts List or shown in the Exploded View. The symbol number should not be used for ordering purposes.

## SONY CORPORATION

© 1972